



GALAXY (2006 - 2015)



The prices shown on our website are per bush.

To get the total pack price you will need to multiple this price by the number of bushes per vehicle.

Bush Price x Qty Per Car = Pack Price

- PFF 881030 fits only 2.5L Ford Mondeo ST Model.
- Please check front and rear anti-roll bar size before ordering.

PFF19-1925 FITS LOWER ENGINE MOUNT WITH THIS PROFILE ONLY



In addition to the Road Series parts listed please check the Black Series website for other bushes suitable for this car that may be more suited to Track/Race use.



FRONT ARM FRONT BUSH

Qty Per Car **2**

Diagram Ref. **1**

Part No. **PFF 191901**



FRONT ARM REAR BUSH

Qty Per Car **2**

Diagram Ref. **2**

Part No. **PFF 191902**



FRONT ANTI ROLL BAR TO CHASSIS BUSH 21MM

Qty Per Car **2**

Diagram Ref. **3**

Part No. **PFF 19160321**



FRONT ANTI ROLL BAR TO CHASSIS BUSH 22MM

Qty Per Car **2**

Diagram Ref. **3**

Part No. **PFF 19160322**



FRONT ANTI ROLL BAR TO CHASSIS BUSH 23MM

Qty Per Car **2**

Diagram Ref. **3**

Part No. **PFF 19160323**



FRONT ANTI ROLL BAR TO CHASSIS BUSH 24MM

Qty Per Car **2**

Diagram Ref. **3**

Part No. **PFF 19160324**



FRONT ANTI ROLL BAR TO CHASSIS BUSH 25.5MM

Qty Per Car **2**

Diagram Ref. **3**

Part No. **PFF 19160325.5**



REAR UPPER ARM BUSH

Qty Per Car **4**

Diagram Ref. **11**

Part No. **PFR 191911**



REAR LOWER ARM INNER BUSH

Qty Per Car **2**

Diagram Ref. **13**

Part No. **PFR 191913**



REAR LOWER ARM OUTER BUSH

Qty Per Car **2**

Diagram Ref. **14**

Part No. **PFR 191914**



REAR TOE LINK ARM BUSH

Qty Per Car **4**

Diagram Ref. **15**

Part No. **PFR 191915**



REAR TRAILING ARM BUSH

Qty Per Car **2**

Diagram Ref. **17**

Part No. **PFR 191917**



REAR ANTI ROLL BAR TO LINK ROD BUSH

Qty Per Car **2**

Diagram Ref. **18**

Part No. **PFR 191918**

inc. VAT



REAR SUBFRAME FRONT BUSH INSERTS

Qty Per Car **2**

Diagram Ref. **20**

Part No. **PFR 191920**



REAR SUBFRAME REAR BUSH INSERTS

Qty Per Car **2**

Diagram Ref. **21**

Part No. **PFR 191921**



REAR SUBFRAME BUSH

Qty Per Car **4**

Diagram Ref. **22**

Part No. **PFR 191922**



LOWER ENGINE MOUNT INSERT

Qty Per Car **1**

Diagram Ref. **25**

Part No. **PFF 191925**



TORQUE ROD INSERT

Qty Per Car **1**

Diagram Ref. **30**

Part No. **PFF 881030**
