

## **E46 3 SERIES INC TOURING**

The prices shown on our website are <u>per bush</u>. To get the total pack price you will need to multiple this price by the number of bushes per vehicle.

## Bush Price x Qty Per Car = Pack Price

Notes:

- PFF5-4601 & PFF5-5601 fit brackets with a 66mm bore
- PFF5-4601-60 & PFF5-5601-60 fit brackets with a 60mm bore , usually found on earlier models.
- PFF5-5601G & PFF5-5601G-60 give an additional +0.5° Caster
- PFR5-4610 & 4611 are complete replacement bushes, for inserts use PFR5-4613 & 4614 (inserts fit into the voiding of the original bush)
- PFR5-4615G replaces the original arm and inner bush and allows on car adjustment of camber. For a replacement bush only to fit in the original arm, please use PFR5-4616.
- PFR5-5630-10 fits cars with standard or aftermarket rear shock absorber with a 10mm pin, PFR5-5630-12 fits cars with aftermarket rear shock absorbers with a 12mm pin. Neither fit Cabriolet models

In addition to the Black Series parts listed please check the Road Series website for other bushes suitable for this car such as engine or transmission mountings.

	E46 3 SERIES		
		30 30 0 0 0 0 0 0 0 0 0 0 0 0 0	

POWERCLEX Grack Forker Reported to the vertex	FRONT WISHBONE REAR BUSH, ALUMINIUM OUTER				
085	Qty Per Car <b>2</b>	Diagram Ref. <b>1</b>	Part No. <b>PFF5-5601-60BLK</b>		
Powierclex Unck sone Network interve	FRONT WISHBONE	REAR BUSH, ALUMINIUM OU	TER		
08)	Qty Per Car <b>2</b>	Diagram Ref. <b>1</b>	Part No. <b>PFF5-5601BLK</b>		
Power/second	FRONT WISHBONE	REAR BUSH, CASTER OFFSE	г		
	Qty Per Car 2	Diagram Ref. <b>1</b>	Part No. <b>PFF5-5601G-60BLK</b>		
POWERFILEX California Contection	FRONT WISHBONE REAR BUSH, CASTER OFFSET				
	Qty Per Car 2	Diagram Ref. 1	Part No. PFF5-5601GBLK		
POWERHEEX March Solites March March	FRONT WISHBONE REAR BUSH				
	Qty Per Car 2	Diagram Ref. <b>1</b>	Part No. <b>PFF5-4601-60BLK</b>		
POWER/FLEX Grad STATE	FRONT WISHBONE REAR BUSH				
	Qty Per Car 2	Diagram Ref. 1	Part No. <b>PFF5-4601BLK</b>		

POWTERFLEX CARCE SOUTH	FRONT ANTI ROLL BA					
	Qty Per Car <b>2</b>	Diagram Ref. 2	Part No. <b>PFF5-4602-21BLK</b>			
	FRONT ANTI ROLL BAR BUSH 23.5MM					
	Qty Per Car <b>2</b>	Diagram Ref. 2	Part No. <b>PFF5-4602-23.5BLK</b>			
Pomensus (	FRONT ANTI ROLL BA	AR BUSH 23MM				
	Qty Per Car <b>2</b>	Diagram Ref. 2	Part No. <b>PFF5-4602-23BLK</b>			
POWERELEX	FRONT ANTI ROLL BA	AR BUSH 24MM				
	Qty Per Car <b>2</b>	Diagram Ref. 2	Part No. <b>PFF5-4602-24BLK</b>			
Powerteter	FRONT ANTI ROLL BA	AR BUSH 26MM				
	Qty Per Car <b>2</b>	Diagram Ref. <b>2</b>	Part No. <b>PFF5-4602-26BLK</b>			
POWERELEX CHeck Some	FRONT ANTI ROLL BA	AR MOUNTING BUSH 27MM				
	Qty Per Car <b>2</b>	Diagram Ref. 2	Part No. <b>PFF5-4602-27BLK</b>			
Powenteek	FRONT ANTI ROLL BA	AR BUSH 30.8MM				
	Qty Per Car <b>2</b>	Diagram Ref. <b>2</b>	Part No. <b>PFF5-4602-30.8BLK</b>			
	REAR TRAILING ARM	AILING ARM BUSH				
	Qty Per Car <b>2</b>	Diagram Ref. <b>3</b>	Part No. <b>PFR5-3608BLK</b>			
	REAR ROLL BAR MOU	REAR ROLL BAR MOUNTING BUSH 15MM				
	Qty Per Car 2	Diagram Ref. <b>4</b>	Part No. <b>PFR5-504-15BLK</b>			
	REAR ROLL BAR MOUNTING BUSH 18MM					
	Qty Per Car <b>2</b>	Diagram Ref. <b>4</b>	Part No. <b>PFR5-504-18BLK</b>			
POWERELEX Build and a Market	REAR ROLL BAR MOUNTING BUSH 19MM					
	Qty Per Car <b>2</b>	Diagram Ref. 4	Part No. <b>PFR5-504-19BLK</b>			
PONTERFLEX SPECK SCIENCE	REAR ROLL BAR MOUNTING BUSH 20MM					
	Qty Per Car 2	Diagram Ref. 4	Part No. <b>PFR5-504-20BLK</b>			

	REAR SUBFRAME FRONT BUSH					
	Qty Per Car <b>2</b>	Diagram Ref. <b>10</b>	Part No. <b>PFR5-4610BLK</b>			
POWERFLEX	REAR SUBFRAME FRONT BUSH INSERT					
00	Qty Per Car <b>2</b>	Diagram Ref. <b>10</b>	Part No. <b>PFR5-4614BLK</b>			
POWERELEX Charles Scritter Applied From Any Long	REAR SUBFRAME REAR BUSH					
e fo	Qty Per Car <b>2</b>	Diagram Ref. <b>11</b>	Part No. <b>PFR5-4611BLK</b>			
POWERELEX COLOR SOLOS Real Friday Solos Real Friday Solos	REAR SUBFRAME REAR B	REAR SUBFRAME REAR BUSH INSERT				
00	Qty Per Car <b>2</b>	Diagram Ref. <b>11</b>	Part No. <b>PFR5-4613BLK</b>			
POWERELEX	REAR UPPER ARM INNER	BUSH				
	Qty Per Car <b>2</b>	Diagram Ref. <b>17</b>	Part No. <b>PFR5-4617BLK</b>			
POWERELEX CONCERSION WINDOW SUBJECT	REAR LOWER ARM OUTER	REAR LOWER ARM OUTER BUSH				
9-10	Qty Per Car <b>2</b>	Diagram Ref. <b>18</b>	Part No. <b>PFR5-4618BLK</b>			
	ADJUSTABLE REAR LOWER CONTROL ARM KIT					
	Qty Per Car <b>1</b>	Diagram Ref. <b>19</b>	Part No. <b>PFR5-4615G</b>			
POMERELEX Shark Source with the state	REAR LOWER CONTROL A	REAR LOWER CONTROL ARM INNER BUSH				
	Qty Per Car <b>2</b>	Diagram Ref. <b>19</b>	Part No. <b>PFR5-4616BLK</b>			
	REAR DIFF FRONT BUSH					
	Qty Per Car <b>2</b>	Diagram Ref. <b>25</b>	Part No. <b>PFR5-4625BLK</b>			
	REAR DIFF REAR BUSH					
So	Qty Per Car <b>1</b>	Diagram Ref. <b>26</b>	Part No. <b>PFR5-4626BLK</b>			
POWERTIEK Girak Estration	REAR SHOCK TOP MOUNT BRACKET AND BUSH 10MM					
	Qty Per Car <b>2</b>	Diagram Ref. <b>30</b>	Part No. <b>PFR5-5630-10BLK</b>			
	REAR SHOCK TOP MOUNT BRACKET AND BUSH 12MM					
	Qty Per Car <b>2</b>	Diagram Ref. <b>30</b>	Part No. <b>PFR5-5630-12BLK</b>			