

850, S70, V70 (UP TO 2000)

PRICING INFORMATION

The prices shown on our website are <u>per bush</u>. To get the total pack price you will need to multiple this price by the number of bushes per vehicle.

Bush Price x Qty Per Car = Pack Price

<u>Notes</u>


- PFF 88101 Does Not Fit All Wheel Drive, Diesel Or Police Models
- PFF 88106 Fits Petrol Models Only With The Later Superseded Bracket Volvo Supply As A Replacement For All Models Or Fitted As Standard To 70 Series Year 1999 To 2000 (50mm Diameter Bush)
- PFF 88107 Fits Petrol Models With The Original Bracket (36mm Diameter Bush)
- PFR 88901 Fits Front Wheel Drive Vehicles Only

In addition to the Road Series parts listed please check the Black Series website for other bushes suitable for this car that may be more suited to Track/Race use.



FRONT WISHBONE LOWER BUSH Qty Per Car 4 Diagram Ref. 1

	FRONT UPPER ENGINE MOUNTING		
	Qty Per Car 1	Diagram Ref. 2	Part No. PFF 88105
	FRONT SUB FRAME MOUNT INSERT		
	Qty Per Car 4	Diagram Ref. 20	Part No. PFF 88120
	FRONT UPPER BULKHEAD MOUNT 50MM		
8 8 8	Qty Per Car 1	Diagram Ref. 3	Part No. PFF 88106
	FRONT UPPER BULKHEAD MOUNT 36MM		
	Qty Per Car 1	Diagram Ref. 3	Part No. PFF 88107
	POWERALIGN CAMBER BOLT KIT (12MM)		
	Qty Per Car 1	Diagram Ref.	Part No. PFA100-12



Part No. **PFF 88101**

FRONT LOWER ENGINE TIE BAR LARGE BUSH



Qty Per Car **1**

Qty Per Car **2**

Diagram Ref. 10

Part No. **PFF 88711**



FRONT LOWER ENGINE MOUNT SMALL BUSH

Qty Per Car **1**

Diagram Ref. **11**

Part No. **PFF 88611**

REAR LOWER SHOCK BUSH

Diagram Ref. 15

Part No. **PFR 88901**