




XC70 (2007 - 2011)

The prices shown on our website are per bush.
To get the total pack price you will need to multiple this price by the number of bushes per vehicle.


Bush Price x Qty Per Car = Pack Price

- Please check front and rear anti-roll bar size before ordering.

PFF19-1925 FITS LOWER ENGINE MOUNT WITH THIS PROFILE ONLY



In addition to the Road Series parts listed please check the Black Series website for other bushes suitable for this car that may be more suited to Track/Race use.



POWERALIGN CAMBER BOLT KIT (14MM)

Qty Per Car **1**

Diagram Ref. **N/A**

Part No. **PFA100-14**



FRONT LOWER WISHBONE FRONT BUSH

Qty Per Car **2**

Diagram Ref. **1**

Part No. **PFF 88601**



FRONT ARM FRONT BUSH

Qty Per Car **2**

Diagram Ref. **1**

Part No. **PFF 191901**



FRONT ARM REAR BUSH

Qty Per Car **2**

Diagram Ref. **2**

Part No. **PFF 191902**



FRONT ANTI ROLL BAR TO CHASSIS BUSH 22MM

Qty Per Car **2**

Diagram Ref. **3**

Part No. **PFF 19160322**



REAR ANTI-ROLL BAR BUSH

Qty Per Car **2**

Diagram Ref. **10**

Part No. **PFR 19191020.3**



REAR UPPER ARM BUSH

Qty Per Car **4**

Diagram Ref. **11**

Part No. **PFR 191911**



REAR LOWER ARM INNER BUSH

Qty Per Car **2**

Diagram Ref. **13**

Part No. **PFR 191913**



REAR LOWER ARM OUTER BUSH

Qty Per Car **2**

Diagram Ref. **14**

Part No. **PFR 191914**



REAR TOE LINK ARM BUSH

Qty Per Car **4**

Diagram Ref. **15**

Part No. **PFR 191915**



REAR ANTI ROLL BAR TO LINK ROD BUSH

Qty Per Car **2**

Diagram Ref. **18**

Part No. **PFR 191918**



REAR SUBFRAME FRONT BUSH INSERTS

Qty Per Car **2**

Diagram Ref. **20**

Part No. **PFR 191920**



REAR SUBFRAME REAR BUSH INSERTS

Qty Per Car **2**

Diagram Ref. **21**

Part No. **PFR 191921**



REAR SUBFRAME BUSH

Qty Per Car **4**

Diagram Ref. **22**

Part No. **PFR 191922**
