

POWERALIGN

CAMBER KITS

Manufacturer	Model	From	To	Front Camber PowerAlign	Rear Camber PowerAlign				
Alfa Romeo	Alfa 145/146	1994	2001	PFA100-12					
Alfa Romeo	Alfa 155	1992	1998	PFA100-12					
Alfa Romeo	GTV	1995	2005	PFA100-12					
Alfa Romeo	Spider (916)	1995	2006	PFA100-12					
Audi	80/90	1986	1991	PFA100-12					
Audi	80 inc quattro	1991	1996	PFA100-14					
Audi	Coupe	1989	1996	PFA100-12					
Audi	Cabriolet	1992	2000	PFA100-14					
BMW	X5 E53	2000	2006	PFA100-16					
Chevrolet	Cruze JG/JH	2009	on	PFA100-12					
Chrysler	Neon	1994	2007	PFA100-14	PFA100-12				
Chrysler	PT Cruiser	2000	2010	PFA100-14					
Chrysler	SRT4	2003	2005	PFA100-14					
Chrysler	Vision	1994	1997	PFA100-16					
Chrysler	Voyager/Grand Voyager	1996	2011	PFA100-14					
Chrysler	300M	1998	2004	PFA100-16		£			
Chevrolet	Captiva	2006	2011	PFA100-14					
Chevrolet	Epica	2006	2007	PFA100-12					
Chevrolet	Kalos	2000	2011	PFA100-12					
Chevrolet	Lacetti	2003	2010	PFA100-12					
Daewoo	Captiva	2006	2010	PFA100-14					
Daewoo	Lanos	1997	2003	PFA100-12					
Daewoo	Leganza	1999	2004	PFA100-12	PFA100-12				
Daewoo	Matiz	1999	2004	PFA100-12					
Daewoo	Nubira	1997	2009	PFA100-12	PFA100-12				
Daihatsu	Applause	1989	1999	PFA100-12					
Daihatsu	Charade G10, G11, G100, G200	1980	2000	PFA100-12	PFA100-12				
Daihatsu	Charade G202, G203	1993	2000	PFA100-15	PFA100-12	£			
Daihatsu	Cuore	1997	2002	PFA100-12					
Daihatsu	GranMove&Move	1997	2002	PFA100-12					
Daihatsu	Sirion	1998	2005	PFA100-12					
Daihatsu	Terios	1997	2005	PFA100-12					
Dodge	Avenger	2007	2011	PFA100-14					
Dodge	Caliber	2007	2011	PFA100-14					
Dodge	SRT4	2003	2005	PFA100-14					

Manufacturer	Model	From	To	Front Camber PowerAlign	Rear Camber PowerAlignP				
Fiat	128	1970	1978	PFA100-12					
Fiat	500	1997	on	PFA100-12					
Fiat	Barchetta	1995	2005	PFA100-12					
Fiat	Bravo/Brava	1995	2001	PFA100-12					
Fiat	Cinquecento	1991	1998	PFA100-12					
Fiat	Coupe	1994	2000	PFA100-12					
Fiat	Croma	1986	2011	PFA100-12					
Fiat	Fiorino	1994	2001	PFA100-12					
Fiat	Multipla	1998	2007	PFA100-12					
Fiat	Panda	2003	on	PFA100-12					
Fiat	Punto	1993	2003	PFA100-12					
Fiat	Seicento	1998	2010	PFA100-12					
Fiat	Strada	1998	2010	PFA100-12					
Fiat	Ulysse	1995	2002	PFA100-12					
Fiat	X1/9	1978	1983	PFA100-12					
Ford	Fiesta	1985	1989	PFA100-12					
Ford	Fiesta VI	2008	on	PFA100-12					
Ford	Mondeo	2007	2013	PFA100-14					
Ford	Probe	1994	1998	PFA100-12					
Ford	S-Max	2006	2010	PFA100-14					
Honda	Civic	2001	2011	Please check bolt size PFA100-14 or PFA100-16					
Honda	Civic EP3 Type R	2001	2005	PFA100-16					
Honda	Civic FK/FN 1,2,3 Type R	2006	2011	PFA100-16					
Honda	CR-V	2002	2011	PFA100-16					
Honda	Element	2003	2009	PFA100-16					
Honda	FR-V	2004	2007	PFA100-16					
Honda	Integra Type-R/S DC3	2001	2006	PFA100-15					
Honda	Integra DC5	2001	2006	PFA100-16					
Honda	Jazz	2001	2011	PFA100-14					
Hyundai	Accent	1995	2005	PFA100-12	PFA100-12				
Hyundai	Coupe	1999	2009	PFA100-12					
Hyundai	Elantra/Lantra	1991	2011	PFA100-12	PFA100-12				
Hyundai	Excel	1985	1994	PFA100-12					
Hyundai	Getz	2002	2012	PFA100-12					
Hyundai	i30/i35	2007	on	PFA100-14					
Hyundai	Santa Fe	2001	2011	PFA100-14					
Hyundai	Scoupe	1991	1996	Please check bolt size PFA100-14 or PFA100-16					
Hyundai	Sonata	1990	1998	PFA100-12					
Hyundai	Sonata	1989	1998	PFA100-14					
Hyundai	Tuscon	2005	2011	PFA100-14					
Hyundai	Velostar	2011	on	PFA100-14					
Infiniti	FX35/45	2003	2008	PFA100-14					
Infiniti	QX4	1997	2003	PFA100-14					
Jeep	Patriot	2007	2011	PFA100-14					
Jeep	Compass - 4x4	2007	2011	PFA100-14					
Kia	Carens	2002	2007	PFA100-12					
Kia	Carens	2007	2010	PFA100-14					
Kia	Clarus	1999	2000	PFA100-14					
Kia	Magentis	2007	2011	PFA100-14					
Kia	Mentor	1994	2001	PFA100-12	PFA100-12				
Kia	Rio	2000	2011	PFA100-12					
Kia	Sedona	1999	2011	PFA100-14					
Kia	Soul	2010	2011	PFA100-14					
Kia	Sportage	2005	2011	PFA100-14	PFA100-14				
Kia	Venga	2009	2011	PFA100-14					
Lancia	HF/Integrale	1989	1999	PFA100-12					
Lancia	Kappa	1994	2001	PFA100-12					
Lancia	Lybra	1999	2006	PFA100-12					

Manufacturer	Model	From	To	Front Camber PowerAlign	Rear Camber PowerAlignP				
Land Rover	Freelander	2000	2006	PFA100-14	PFA100-14				
Land Rover	Range Rover	2003	2009	PFA100-16					
Lexus	RX300/350/400h	1999	2010	PFA100-17	PFA100-15				
Mazda	2	2011	on	PFA100-12					
Mazda	121	1987	1996	PFA100-12					
Mazda	323	1981	2003	PFA100-12	PFA100-12				
Mazda	626	1978	2001	PFA100-12	PFA100-12				
Mazda	929	1988	1991	PFA100-12					
Mazda	CX-5	2013		PFA100-16					
Mazda	CX-7	2007	2011	PFA100-14					
Mazda	Mazda 2/121/Demio	2007	2011	PFA100-12					
Mazda	MX-3	1992	1998	PFA100-12	PFA100-12				
Mazda	MX-6	1988	1998	PFA100-12	PFA100-12				
Mazda	RX-7	1986	1992	PFA100-12					
Mercedes	C-Class W204	2008	2013	PFA100-14					
Mercedes	E-Class W212	2010	2013	PFA100-15					
Mercedes	Sprinter	2007	2010	PFA100-16					
Mitsubishi	3000GT	1992	1998	PFA100-12					
Mitsubishi	GTO	1992	1998	PFA100-12					
Mitsubishi	Carisma	1995	2004	PFA100-12					
Mitsubishi	Colt RC RD RE	1984	1990	PFA100-12					
Mitsubishi	Colt	2003	2011	PFA100-12					
Mitsubishi	Eclipse	1990	1993	PFA100-12					
Mitsubishi	Eclipse	2000	2012	PFA100-16					
Mitsubishi	FTO	1994	1999	PFA100-12					
Mitsubishi	Galant	1999	2010	PFA100-16					
Mitsubishi	Galant	1985	1993	PFA100-12					
Mitsubishi	Lancer CA to CH	1998	2008	PFA100-12					
Mitsubishi	Evo 3, 4, 5, 6,	1992	2001	PFA100-12					
Mitsubishi	Evo 7, 8, 9, X	2002	2013	PFA100-14					
Mitsubishi	Outlander	2003	2013	PFA100-14					
Mitsubishi	Sigma	1991	1996	PFA100-12					
Mitsubishi	Space Runner	1991	2000	PFA100-12					
Mitsubishi	Space Star	1998	2005	PFA100-12					
Nissan	180SX & 200SX (S13)	1984	1994	PFA100-12					
Nissan	200 SX S14 & S15	1995	2002	PFA100-12					
Nissan	Almera	1995	2006	PFA100-12					
Nissan	Almera	2007	2011	PFA100-14					
Nissan	Altima	1993	1997	PFA100-12					
Nissan	Cube	2009	on	PFA100-14					
Nissan	Juke	2011	on	PFA100-14					
Nissan	Leaf	2011	on	PFA100-14					
Nissan	Maxima	1988	1994	PFA100-12					
Nissan	Maxima	1995	2013	PFA100-14					
Nissan	Micra (K11)	1992	2002	PFA100-12					
Nissan	Micra (K12)	2003	2009	PFA100-12					
Nissan	Micra (K13)	2010	2011	PFA100-12					
Nissan	Murano	2003	2011	PFA100-14					
Nissan	Note/Tiida	2006	2011	PFA100-14					
Nissan	Pathfinder	1996	2004	PFA100-14					
Nissan	Pixo	2000	2011	PFA100-12					
Nissan	Primera	1990	1996	PFA100-12	PFA100-12				
Nissan	Pulsar N10-N16 inc GTiR	1981	2006	PFA100-12					
Nissan	QX (Maxima)	1995	2007	PFA100-14		£			
Nissan	Silvia	1993	2002	PFA100-12					
Nissan	Stanza	1982	1986	PFA100-12					
Nissan	Sunny/100 NX)	1990	1995	PFA100-12	PFA100-12				
Nissan	Terrano II	1997	2004	PFA100-14					
Nissan	Tiida	2006	2012	PFA100-14					
Nissan	Vanette	1991	1996	PFA100-12					
Nissan	X-Trail	2000	2007	PFA100-12					
Nissan	X-Trail	2008	2011	PFA100-14					

Manufacturer	Model	From	To	Front Camber PowerAlign	Rear Camber PowerAlignP				
Peugeot	806	1994	2001	PFA100-12					
Porsche	924	1976	1982	PFA100-12					
Porsche	944	1982	1983	PFA100-12					
Renault	Clio	1990	1998	PFA100-12					
Renault	Clio II	1998	2004	PFA100-14					
Renault	Kangoo	1998	2011	PFA100-14					
Renault	Megane I	1995	2002	PFA100-12					
Renault	Megane II	2002	2007	PFA100-14					
Renault	Safrane	1992	1999	PFA100-16					
Renault	Scenic	1997	2002	PFA100-14					
Renault	Twingo	1993	2011	PFA100-12					
Renault	R5	1985	1995	PFA100-12					
Renault	R9/11	1982	1989	PFA100-12					
Renault	R19	1991	1996	PFA100-12					
Renault	R21	1989	1997	PFA100-12 or PFA100-14 check before ordering					
Rover	Maestro	1989	1998	PFA100-12					
Rover	Montego	1989	1994	PFA100-12					
Saab	9000	1984	1998	PFA100-12					
Saab	9-2X	2005	2007	PFA100-14	PFA100-14				
Saab	9-3 (93)	1998	2011	PFA100-12					
Saab	9-5 (95)	1997	2011	PFA100-12					
Seat	Arosa	1997-	2004	PFA100-12					
Seat	Ibiza 2/Cordoba 1	1993-	2001	PFA100-12					
Seat	Inca	1996	2003	PFA100-12					
Seat	Toledo 1	1991	1998	PFA100-12					
Subaru	BRZ	2012	-	PFA100-14					
Subaru	Forester	1998	2011	PFA100-14	PFA100-14				
Subaru	Impreza	1993	2007	PFA100-14	PFA100-14				
Subaru	Impreza WRX	1993	2007	PFA100-14	PFA100-14				
Subaru	Impreza WRX STI UK	1998	2007	PFA100-14	PFA100-14				
Subaru	Impreza, WRX, STi	2008	2011	PFA100-14					
Subaru	Legacy	1989	1999	PFA100-14	PFA100-14				
Subaru	Legacy	2000	2011	PFA100-14					
Subaru	Outback	1997	2011	PFA100-14	PFA100-14				
Subaru	Tribeca	2006	2011	PFA100-14					
	SVX	1992	1997	PFA100-14					
Subaru	XV Crosstek	2012	on	PFA100-15					
Suzuki	Alto	1987	2011	PFA100-12					
Suzuki	Baleno	1995	2007	PFA100-12	PFA100-12				
Suzuki	Ignis	2000	2007	PFA100-12					
Suzuki	Liana	2001	2007	PFA100-12	PFA100-12				
Suzuki	SX4	2006	2011	PFA100-12					
Suzuki	Splash	2008	2011	PFA100-12					
Suzuki	Swift	1985	2010	PFA100-12					
Suzuki	Vitara/Grand Vitara	1989	2011	PFA100-12					
Suzuki	X 90	1996	1998	PFA100-12					
Suzuki	Wagon R	1997	2007	PFA100-12					

Manufacturer	Model	From	To	Front Camber PowerAlign	Rear Camber PowerAlignP				
Toyota	Avensis	2003	2011	PFA100-17					
Toyota	Auris	2007	2011	PFA100-17					
Toyota	Camry	1983	2010	PFA100-17					
Toyota	Carina	1989	1998	PFA100-15	PFA100-15	£			
Toyota	Celica ST165 GT4	1985	1989	PFA100-12					
Toyota	Celica	1986	1999	PFA100-15	PFA100-15				
Toyota	Celica	2000	2005	PFA100-15					
Toyota	Corolla AE80, 82, 90, 92, 93, 94, 95, 101, 102, 112	1985	2001	PFA100-12/PFA100- 15 Check bolt size before ordering					
Toyota	Corolla	1988	2002	PFA100-15	PFA100-15				
Toyota	Corolla	2003	2008	PFA100-15					
Toyota	Corolla	2009	2011	PFA100-15					
Toyota	GT-86	2012	-	PFA100-14					
Toyota	MR 2 AW11, SW20	1987	1990	PFA100-12	PFA100-12				
Toyota	MR 2	1991	1997	PFA100-15	PFA100-15				
Toyota	MR2 ZZW30	2000	2006	PFA100-15	PFA100-15				
Toyota	Paseo	1992	1997	PFA100-15					
Toyota	Prius	2001	2009	PFA100-15					
Toyota	Prius	2010	2011	PFA100-17					
Toyota	Previa	1990	1997	PFA100-17					
Toyota	RAV-4	2001	2005	PFA100-15					
Toyota	RAV-4	2006	2011	PFA100-17					
Toyota	Starlet	1979	1999	PFA100-15					
Toyota	Urban Cruiser	2009	2011	PFA100-15					
Toyota	Verso	2010	2011	PFA100-17					
Toyota	Yaris	2007	2011	PFA100-15					
Vauxhall-Opel	Ampera	2011	on	PFA100-12					
Vauxhall-Opel	Antara	2007	2011	PFA100-14					
Vauxhall-Opel	Astra-F	1991	1998	PFA100-12					
Vauxhall-Opel	Astra-G/H	1998	2010	PFA100-12					
Vauxhall-Opel	Astra-J Mk6	2010	on	PFA100-12					
Vauxhall-Opel	Calibra	1990	1998	PFA100-12					
Vauxhall-Opel	Corsa A	1984	1993	PFA100-12					
Vauxhall-Opel	Corsa B	1993	1999	PFA100-12					
Vauxhall-Opel	Corsa C	2000	2006	PFA100-12					
Vauxhall-Opel	Corsa D/VXR	2007	2011	PFA100-12					
Vauxhall-Opel	Meriva	2002	2011	PFA100-12					
Vauxhall-Opel	Senator B	1987	1994	PFA100-12					
Vauxhall-Opel	Omega/Carlton	1987	2003	PFA100-12					
Vauxhall-Opel	Signum	2003	2008	PFA100-12					
Vauxhall-Opel	Sintra	1997	1999	PFA100-14					
Vauxhall-Opel	Tigra	1994	2009	PFA100-12					
Vauxhall-Opel	Vectra B	1995	2001	PFA100-12					
Vauxhall-Opel	Vectra C	2002	2011	PFA100-12					
Vauxhall-Opel	Zafira	1999	2011	PFA100-12					
Volkswagen	Corrado	1990	1997	PFA100-12					
Volkswagen	Golf 1	1974	1983	PFA100-12					
Volkswagen	Golf 2 & 3	1984	1998	PFA100-12					
Volkswagen	Jetta	1974	1983	PFA100-12					
Volkswagen	Jetta	1984	1990	PFA100-12					
Volkswagen	Jetta	1991	1998	PFA100-12					
Volkswagen	Lupo	1998	2005	PFA100-12					
Volkswagen	Passat	1988	1996	PFA100-12					
Volkswagen	Polo I & II	1982	1993	PFA100-12					
Volkswagen	Vento	1991	1998	PFA100-12					
Volvo	400 Series	1986	1997	PFA100-12					
Volvo	850	1992	1997	PFA100-12					
Volvo	960	1995	1997	PFA100-12					
Volvo	S40 / V40	1996	2004	PFA100-12					
Volvo	S80			PFA100-14					
Volvo	S60	2000	2011	PFA100-14					
Volvo	S / V / C70	1998	2000	PFA100-12					
Volvo	V70	2001	2007	PFA100-14					
Volvo	XC70/90	2002	2011	PFA100-14					